

IX Series 2

Paging


GENERAL OVERVIEW:

Group Calls/Pages are initiated by a master station using a speed dial button. A Group Call places a call to all stations in a group with the intention of one of those stations answering to establish two-way communication. A Group Page is used when one-way communication is needed to all stations in a group.

Table of Contents


Page 1-2	Creating a Group <i>- Create a group of stations to page to</i>
Page 2-3	Setting a Speed Dial Button <i>- Set a Speed Dial on the master station to page a group of stations</i>
Page 4	Paging Settings <i>- Adjust the paging timeout settings</i>
Page 5-6	All Page Settings <i>- Add stations to All Page and set a Speed Dial button to page them</i>
Page 7-8	Option Input Paging <i>- Configure a station's Option Input to page</i>

Creating a Group



1.1 - Station View
Switch from Table View to Station View by clicking the Station View button in the top left-hand of Support Tool.

1.2 - System Information / Group
Expand **System Information** and click **Group (for Master)**.



1.3 - Select a Station
Use the drop-down menu to choose the station number of the master station to be configured and click **Select**.

Creating a Group (cont.)

1.4 - Group Number
Enter a **Group Number**.

1.5 - Group Name
Enter a **Group Name**.

•Group (for Master)

U = Unicast, M = Multicast
If designating "M", multicast IP addresses must be configured for the station(s).
To register a VoIP Phone, go to Network Settings -> SIP and enter the IP address of the SIP Primary Server.
Only one VoIP Phone can be set per group.

#	Station Information				System Information			
	Identification				Group List			
	Number	Name	Location	Station Type	01		02	
					Audio Protocol	Video Protocol	Audio Protocol	Video Protocol
Group Number					01			
Group Name					Door Stations			
Group Name (furigana)								
Total					4	0	0	0
0001	102	Security Desk		IX-MV7-*				
0002	201	IX-DV - Front Door		IX-DV, IX-DVF(-)	U			
0003	202	IX-DVF-2RA - Parking Lot		IX-DV, IX-DVF(-)	U			
0004	203	IX-SS-2G - Employee Door		IX-SS-2G	U			
0005	204	IX-SS-2G - Side Entrance		IX-SS-2G	U			
0006	301	IX-RS - Hallway Station		IX-RS-*				
0007	501	Office		VoIP Phone	-	-	-	-

Note:

Multicast is required when calling more than 50 stations. Multicast may also be utilized to reduce network latency when calling or paging multiple stations, however additional network configuration may be required to allow the use of this protocol. Contact the network administrator if the use of Multicast is needed.

1.6 - Select an Audio Protocol

Use the drop-down menu next to each station and select a broadcasting protocol (U/M) under **Audio Protocol** to add it to this group.

If a master station is part of a group, a **Video Protocol** may be set for master to master video conferencing during a group call or page.

Note: It is recommended that Multicast is used if paging or group calling utilizing master to master video conferencing. See the previous notation for more information.




1.7 - Update

Click the Update button to save changes.


To configure groups for other master stations, return to Select Station to Edit, use the drop-down menu to choose another station, and click Select.

Setting a Speed Dial Button




2.1 - Station View
Switch from **Table View** to **Station View** by clicking the **Station View** button in the top left-hand of Support Tool.

2.2 - Speed Dials / Favorites
Expand **Station Settings** and click **Speed Dials / Favorites**.



2.3 - Select a Station
Use the drop-down menu to choose the station number of the master station to be configured and click **Select**.



2.4 - Speed Dial Name
Enter a **Name** for the Speed Dial.


2.5 - Group Page
Select **Group Page** and enter a Group number in the adjacent box.

2.6 - Priority
Set a Priority for the **Group Page**.




2.7 - Update
Click the Update button.

Paging Settings



3.1 - Station View
Switch from **Table View** to **Station View** by clicking the **Station View** button in the top left-hand of Support Tool.

3.2 - Paging Settings
Expand **Paging Settings** and click **Paging Origination**.



Paging Timeout
Choose the length of the page before an automatic timeout in **Paging Timeout**.

Paging Wait Timer
The time allowed to lapse while the master station is awaiting a response for stations to accept the incoming page before the page begins.

Urgent Page Response
Allows the ability to **Enable** or **Disable** a station's ability to end or cancel an incoming urgent page.

Lock Paging
Enable or **Disable** a station's ability to page in Lock Paging.



3.3 - Update
Click the Update button.


Uploading Settings to Stations

Please refer to page 9 for uploading settings to stations.

All Page


All page is an audio only page to all stations in the **All Page** group. To customize paging settings, refer to the previous steps for **Paging Settings**.

An All Page can be placed in two ways, by tapping the Page button on the master station and selecting All Page, or a one-touch speed dial button can be added.



4.1 - Station View
Switch from **Table View** to **Station View** by clicking the **Station View** button in the top left-hand of Support Tool.

4.1 - All Page
Expand **Paging Settings** and click **All Page**.




4.3 Select Stations for All Page
An **All Page** may include up to 50 stations from a master station's address book. Place a check mark next to each station to be included in the **All Page**.
If more than 50 stations are required, use a Group Page.

To configure All Page for other master stations, return to Select Station to Edit, use the drop-down menu to choose another station, and click Select.




4.3 - Update
Click the Update button.

All Page Speed Dial Button




5.1 - Station View
Switch from **Table View** to **Station View** by clicking the **Station View** button in the top left-hand of Support Tool.

5.2 - Speed Dials / Favorites
Expand **Station Settings** and click **Speed Dials / Favorites**.



5.3 - Select a Station
Use the drop-down menu to choose the station number of the master station to be configured and click Select



5.4 - All Page
Click **All Page** radio button. A **Priority** level must also be selected.



5.5 - Update
Click the Update button.

Uploading Settings to Stations

Please refer to page 9 for uploading settings to stations.

Option Input Page

One of the four available option inputs on an IX-MV-7* may be used to trigger a page. To use the **Option Input Page**, **All Page** or **Group Page** must be set first.

- Table View
- Station View**
- Station Information
- Network Settings
- System Information
- Call Settings
- Option Input / Relay Output Settings
 - Option Input**
 - Relay Output
- Paging Settings
- Function Settings
- Transfer Settings
- Station Settings
- Maintenance

6.1 - Station View
Switch from **Table View** to **Station View** by clicking the **Station View** button in the top left-hand of Support Tool.

6.2 - Option Input / Relay Output
Expand **Option Input / Relay Output Settings** and click **Option Input**.

Station Number: 101
Station Name: Front Desk
Location:
Station Type: IX-MV7-*

Select Station to Edit

Type: All
Number: 101

Previous Select Next

6.3 - Select a Station
Use the drop-down menu to choose the station number of the master station to be configured and click **Select**.

Function

- No Function
- Call
() Customize Call in "Call Settings".*
- Answer Call / Page
- Paging**
() Customize Page in "Paging Settings".*
- Message Page
() Customize Message Page in "Paging Settings".*
- External Input Page
() Customize Page in "Paging Settings".
(*) Only one Option Input can be set for External Input Page.*
- Turn LCD On
- Relay Latch Reset
- Bathroom Indicator Reset
- API

6.4 - Function
Click the **Paging** radio button.

6.5 - Update
Click the Update button.

To configure **Option Input Page** for other master stations, return to Select Station to Edit, use the drop-down menu to choose another station, and click Select.

Option Input Page (cont.)

Table View

Station View

- Station Information
- Network Settings
- System Information
- Call Settings
- Option Input / Relay Output Settir
- Paging Settings
 - Paging Origination
 - All Page
 - Option Input Page**
- Function Settings
- Transfer Settings
- Station Settings
- Maintenance

6.6 - Option Input Page
Expand **Paging Settings** and click **Option Input Page**.

●Option Input Page

To configure an Option Input Page, "Page", "Message Page", or "External Input Page" must be selected in Option Input settings.

Option Input #

Destination All Page Group 01-99

Priority Normal Urgent

Message File Name

Play Count [time(s)]

6.7 - Destination
Choose an **All Page** or a **Group** as a **Destination**. If **Group** is selected, type in a group number or click **Open** to choose from a list of groups.

6.8 - Priority
Select either **Normal** or **Urgent** for a **Priority**.




6.9 - Update
Click the Update button.

Uploading Settings to Stations


Please refer to page 9 for uploading settings to stations.

Uploading Settings to Stations

The final step in this process is uploading the setting file to each station.



7.1 - Upload Settings to Station
 From the menu bar select **File** then **Upload Settings To Station**



7.2 - Select Stations
 Click **Select** to check all stations in the system.

7.3 - Upload Settings
 Click **Settings** to begin the upload process.

7.4 - Confirm Status
 Using the **Status** column confirm, that each station has received its setting file.