


IX Series 2

Receptionist Mode

GENERAL OVERVIEW:

Receptionist Mode is a virtual receptionist that allows a user limited access to call lists and other functions to communicate to predetermined locations.

Receptionist Mode




1.1 - Station View

Switch from Table View to Station View by clicking the Station View button in the top left-hand of Support Tool.


1.2 - Display Mode

Expand **Function Settings** and click **Display Mode**.



1.3 - Select a Station

Use the drop-down menu to choose the station number of the master station to be configured and click Select.




1.4 - Receptionist

Click the Receptionist radio button to enable the options listed below.

Text Values and Screen Layouts


2.1 - Color Scheme

Choose the color scheme of the master station's UI by choosing either **Light** or **Dark**.



2.2 - Scene Layout

To adjust the layout of the screen, choose between one of three options.



Company Information

Name 0-40 alphanumeric characters

Text Size 12-24

Bold OFF ON

Text Color Option 1 Option 2

2.3 - Company Information

The company's name is shown at the top of the master station's screen when in Receptionist Mode. **Name** should contain the name of the company, and **Text Size**, **Bold**, and **Text Color** customize this text.

Greeting Information

Greeting 0-100 alphanumeric characters

Text Size 12-70

Bold OFF ON

Text Color Option 1 Option 2

2.4 - Greeting Information

This text is below the Company Information and is used to give a simple greeting or instructional information. Click **Enter** to show a pop-up window to fill in the text with desired spacing, and **Text Size**, **Bold**, and **Text Color** customize this text.

Images

Images

To upload image to the station, upload image file using "Upload Settings To Station".

Company Image Delete

Greeting Image Delete

Receptionist Image Delete

Company Image

Choose an image to appear in the Company Information section.

Recommended resolution (**WxH**) **400x120**, and the file type must be .PNG.

Click **Browse** to choose the image to be uploaded.

This image is not uploaded at this time, this is done in Step 3.

Greeting Image

Choose an image to appear in the Greeting section.

Recommended resolution (**WxH**) **400x240**, and the file type must be .PNG.

Click **Browse** to choose the image to be uploaded.

This image is not uploaded at this time, this is done in Step 3.

Receptionist Image

Choose an image to appear in the background while in Receptionist Mode.

Recommended resolution (**WxH**) **800x340**, and the file type must be .PNG.

Click **Browse** to choose the image to be uploaded.

This image is not uploaded at this time, this is done in Step 3.

*Note: The **Company** and **Greeting** images may be used at the same time. However, the **Receptionist** image will take the place of both the **Company** image and the **Greeting** image when used.*

Button Function

Up to 4 buttons can be added to the Receptionist Mode screen for navigation. Click the drop-down menu for buttons 1-4 and choose between **Group Call**, **Select By Name**, **Select By List**, or **Enter Number**.

Button Function	
Button 1	Group Call
Button 2	Select By Name
Button 3	Select By List
Button 4	Enter Number

Group Call

Call a pre-configured group of stations to receive a call.

Select By Name

Select a station to call in the master station's address book by typing in the destination station's station name.

Select By List

Select a group to call from a list of groups.

A station can be added to its own group to add a single station to the list.

Enter Number

Select a station to call in the master station's address book by typing in the destination station's station number.

If **Group Call** is selected, use **Group Call Destination** to choose a group number of an existing group for the button to call. A group must be created under "System Information > Group".

Group Call Destination	<input type="text"/>	Open Group List	01-99
------------------------	----------------------	-----------------	-------

Reject Incoming Call

Reject Incoming Call	<input type="radio"/> Enable	<input checked="" type="radio"/> Disable
----------------------	------------------------------	--

Reject Incoming Call

Determines if the master station can be called by other stations while in **Receptionist Mode**.

Update




2.5 - Update

Click the Update button to save changes


Uploading Settings

The final step in this process is uploading the setting file to each station. This program file contains the Image files, as well as the Reception Mode settings configured for each station.

Note that without uploading a setting file, most functions and features will be unavailable to the stations.



3.1 - Upload Settings to Station
 From the menu bar select **File** then **Upload Settings To Station**



3.2 - Select Stations
 Click **Select** to check all stations in the system.

3.3 - Upload Settings
 Click **Settings** to begin the upload process.

3.4 - Upload Image
 Click **Image** to begin the upload process.

3.5 - Confirm Status
 Using the **Status** column confirm, that each station has received its setting file.