


■PRODUCT DRAWING




MOUNT ING





DESCRIPTION	FIG. NAME		UNIT	DATE
RESIDENTIAL/TENANT STATION	PRODUCT DRAWING		mm	19 October, 2016
MODEL NO.	FIG. NO.	PAGE	REVISION	AIBHANE
GT-1M3-L	G55568-1-4	1/4	1	AIPHONE

■WIRING DIAGRAM



DESCRIPTION	FIG. NAME		UNIT	DATE
RESIDENTIAL/TENANT STATION	WIRING DIAGRAM		mm	19 October, 2016
MODEL NO.	FIG. NO.	PAGE	REVISION	AIBHANE
GT-1M3-L	G55568-2-4	2/4	1	AIPHONE

■ RESTRICTIONS

- Smooth voice switching for auto voice actuation system may be hindered by talking voice strength or ambient noise, etc.
- Hands-free communication with T-mode hearing aid is effective up to 20 to 30cm from the front of the unit.
- The magnetic field of T-mode hearing aid coil may pass through thin walls.
- Up to 4 Residential/tenant stations can be resistered per one room number.
 Only the following combinations of master stations are possible:
 - GT-1M3-L \times 2 + GT-1A or GT-1D \times Max. 2.
 - $GT-1M3-L \times 1 + GT-1A$ or $GT-1D \times Max. 3$.
- The mounting location shoud be more than 20cm away from other electronic equipment, for example AC units, floor heating controller, wireless router or cordless telephone, etc.
- The mounting location shoud be more than 1m away from radio or TV sets.

■ RESTRICTIONS ON WIRING


• For wiring, it is recommended to use a single PVC jacketed cable with PE(polyethylene) insulation.

The following cables cannot be used;

PARALLEL CABLE

COAXIAL CABLE


ODD NO. OF CONDUCTORS



• Coaxial cable

• Twisted pair cable

• Cable with conductors in odd number



• Unused connector lead wire should be cut and insulated.

■FUNCTIONS


- Receive calls from entrance stations and security guard stations enable communication by pressing the TALK button.
- Call security guard stations, 2-way communication.
- Activate door release by pressing the Door release button (while receiving a call from or communicating with an Entrance station).
- Light control available when receiving a call from an Entrance station
- Receive calls from an optional doorbell.
- Receiving Emergency alarm from optional external devices. (Emergency call tone sounds and transfer is made to Security guard station.)
- Communication/monitor with T-mode accommodating hearing aid.
- TALK indicator lights up in orange while speaking.
- Backlight compensation by pressing ADJUST button while monitor is on. (Low light compensation at night. Distinguishing between day and night is automatically done by the entrance station.)
- ZOOM & WIDE camera control by pressing ZOOM & WIDE button while monitor is on.
- Monitoring audio/video of entrance station by pressing Door release button at stundby, timed out in 30 sec.
- Push-to-talk button for approx. 2 sec. to switch to push-to-talk mode.
- When call tone volume is set 0, status indicator will flash.
- Option button: Controls external device such as entrance light.

DESCRIPTION	FIG. NAME		UNIT	DATE
RESIDENTIAL/TENANT STATION	RESTRICTIONS/FUN	CTIONS	mm	19 October, 2016
MODEL NO.	FIG. NO.	PAGE	REVISION	AIBHANE
GT-1M3-L	G55568-3-4	3/4	1	AIPHONE

■SETTING

- Terminate switch((A: terminated)/B)......SW1

- Residence ID setting (0000 0000~1111 1111(8 bit))...... SW2-1 to 8



■ SPECIFICATIONS

2 01 2011 10/11 10/10					
Power source	DC 24V. Supplied from GT-BC, GT-VBC.				
Type of communication	Hands-free auto-voice actuation				
Type of communication	Push-to-talk communication				
Ambient temperature	0 ~40°C				
Video monitor	3.5 inch TFT color LCD				
Resolution	320 (H) × 240 (V)				
Station capacity	Door bell: 1				
Mounting	Surface wall-mount				
Motoriolo	Unit case: Self-extinguishing PC+ABS resin				
Materials	Panel: Fire-retardant PC				
Color	Snow white (5Y9.3/0.1 Munsell Approximation)				
Weight	Approx. 320g				
DESCRIPTION		FIG. NAME		UNIT	DATE
RESIDENTIAL/TENANT STATION SETTI		SETTING/SPECIFIC	CATIONS	mm	19 October, 2016
MODEL NO.		FIG. NO.	PAGE	REVISION	AIDHONE
GT-1M3-I		G55568-4-4	4/4	1	AIPHONE